UNIQUE - Models UGP 6C/8C/10C

Propane Refrigerators - **Installation and Owners Manual**

WARNING: *Improper installation, adjustment, alteration, service or maintenance can cause injury or property damage. Refer to this manual. For assistance or additional information consult a qualified installer, service agency or the gas supplier.*

!SAVE THESE INSTRUCTIONS!

FOR YOUR SAFETY IF YOU SMELL GAS

Open windows.
Do not touch electrical switches.
Extinguish any open flame
Immediately turn off gas supply and call your gas supplier

FOR YOUR SAFETY

Do not store or use gasoline or other flammable and liquids in the vicinity of this or any other appliance

The installation of the appliance must conform with local codes or, in the absence of local national Fuel Gas Code, ANSI Z233.1 and in Canada B149.2 Propane Storage and Handling Code

May 2012

NOTICE TO INSTALLER/CUSTOMER

Please read carefully before hook-up!

1. The dwelling must have an adequate air supply and access to fresh air/oxygen in order to operate safely. Propane fridges/freezers, like any other gas appliance, must have access to fresh air/oxygen. **T<u>his unvented appliance must not be used in an air-tight application.</u>**

2. This refrigerator must be installed by a licensed gas fitter.

3. The propane gas supply pressure regulator must be set at 11" water column.

4. The left side heat shield (facing front of the refrigerator) must be installed. The heat shield is shipped in the refrigerator carton.

5. For safety & efficient operation the proper clearances on all sides and top must be maintained. The clearances are listed in the Owner's Manual.

6. For proper and efficient operation the refrigerator must be level, both side to side and front to back (use bubble type level).

7. The Combination Carbon Monoxide (CO) Alarm & Safety Shut-Off must be installed and connected (CM Models only) with the Alarm mounted as indicated in the Carbon Monoxide Alarm (Monitor) Installation Manual.

   NOTE: **<u>It is illegal to operate this refrigerator in Canada without the Combination Carbon Monoxide Alarm & Safety Shut-Off installed, and will void the Canadian Standards Association Certification. Non compliance will void the Canadian certification and void household/cottage insurance coverage</u>**. This refrigerator vents combustion products directly into the living space. The CO Alarming Device with Safety Shut-Off has been added to this refrigerator to guard against potentially high levels of Carbon Monoxide, which can kill you. Once unsafe levels of CO are detected, an alarm will sound and the refrigerator will be shut off.

   WARNING: Actuation of this device indicates the presence of unsafe levels of carbon monoxide (CO) which can KILL YOU. If alarm signal sounds:

   a. Immediately move to fresh air --- outdoors or by an open door or window. Check that all persons are accounted for. Do not re-enter the premises or move away from the open door/window until the emergency services responders have arrived, the premises have been aired out, and your alarm remains in its normal condition;

   b. Call emergency local service telephone number, fire department or 911.

   c. The following symptoms may be related to CARBON MONOXIDE POISONING and should be discussed with ALL members of the household:

      Mild Exposure: Headaches, running nose, sore eyes, often described as "flu"-like symptoms;

      Medium Exposure: Dizziness, drowsiness, vomiting;

      Extreme Exposure: Unconscious, brain damage, death.

   d. Read the Instructions for complete Information on Alarms Signals.

8. NOTE: The Combination Carbon Monoxide Alarm & Safety Shut-Off Instructions (CM Model), battery, Owners/Installation Manual are stored inside the refrigerator.
   <u>For Unique Gas Products Support, Call Toll Free 1-877-427-2266</u>

9. Regular maintenance of the fridge is critical to prevent unsafe levels of Carbon Monoxide. Before lighting the refrigerator at any time, clean the flue tube as per the Owner's Manual & make sure the burner and areas around the burner are free from any lint, spider webs or any other debris. Please record your appliance maintenance on the SERVICE RECORD label located at the back of your appliance.

   WARNING -- Test the Combination Carbon Monoxide & Safety Shut-Off device operation after the refrigerator has been in storage, before each start up , and at least once per week during use.

The installation of the refrigerator must conform to the Local Codes. In the absence of a local code:

USA:	*Nation Fuel Gas Code*
Canada:	*CSA B149.1 Natural Gas & Propane Installation Code*
	CSA B149.2 Propane Storage and Handling Code

2245 Wyecroft Road, #5, Oakville, Ontario, Canada L6L 5L7 • Tel: 905-827-6154 • Toll Free: 1-877-427-2266 • Fax: 905-827-2027

www.UniqueOffGrid.com

CERTIFIED AND DISTRIBUTED BY

Unique Gas Products Ltd

"PERSONAL SERVICE & KNOWLEDGE MAKES US UNIQUE"

Unique Gas Products Ltd,
2245 Wyecroft Road #5
Oakville, Ontario, Canada, L6L 5L7
Ph: 905-827-6154 Toll Free: 1-877-427-2266 Fax: 905-827-2027
www.UniqueOffGrid.com
E-mail: info@uniqueoffgrid.com

Table of Contents

Chapters

Welcome	**1**
Safety and Warnings	**1**
Appliance Installation	**2**
General Operating Instructions	**3**
How to use the Refrigerator	**3**
Maintenance & Service	**4**
Troubleshooting & Suggested Spares	**5**
Carbon Monoxide Instructions (CM Model)	**6**
Door Reversal and Removal Instructions	**7**
Temperature Controls, Food Storage and Cleaning	**8**
Parts & Warranty	**9**

Chapter 1

Welcome & Congratulations

Congratulations on your purchase of a UNIQUE refrigerator!. We are very proud of our product and we are completely committed to providing you with the best service possible. Your satisfaction is our #1 priority. Please read this Manual very carefully. It contains valuable information on how to properly maintain your new gas refrigerator.

We know you will enjoy your new refrigerator and Thank You for choosing one of our Unique Gas Products. We hope you will consider us for future purchases.

PLEASE READ AND SAVE THESE INSTRUCTIONS

This manual provides specific operation instructions for your model. Use your refrigerator only as instructed in this manual. These instructions are not meant to cover every possible condition and situation that may occur. Common sense and caution must be practiced when installing, operating and maintaining the appliance

Please record your model and serial # shown below for future reference. This information is found on your CSA rating/serial plate inside the refrigerator compartment.



Please mail in the **Warranty Registration Card** included with you refrigerator.

Safety and Warnings

If you smell gas

- Open Windows
- Don't touch electrical switches
- Extinguish any open flame
- Immedialty call your gas supplier

For you Safety

- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this unit or any other appliance

Warning

- Improper installation, adjustment, alteration, service or maintenance can cause injury or property damage. Refer to this manual. For assistance or additional information consult a qualified installer, service agency or the gas supplier.
- This product can produce Carbon Monoxide. Carbon Monoxide has no odour and can kill you. The burner and flue system must be kept clean. See owner's manual for cleaning instructions.

Installation Instructions

- The installation of the appliance must conform with local codes or, in the absence of local national Fuel Gas Code, ANSI Z233.1 and in Canada B149.2

Chapter

2

Installation

For best performance at high ambient temperatures, there must be free air circulation over the cooling unit at the rear of the refrigerator.

Ensure that there is a free air space above the refrigerator and that the flue (chimney) on top of the cabinet is not covered in any way. Do not place the refrigerator in a space where air circulation is restricted. Follow "clearance" instructions.

This free-standing refrigerator requires accessibility to the back for servicing the gas equipment, which can be obtained by using a certified Flexible Metal Connector to allow the refrigerator to be withdrawn without disrupting the gas supply. "Where a flexible metal connector is used, it must comply with local authorities and in Canada with the provisions of the current Standard CAN 1-6.10, Metal Connectors for Gas Appliances". However, if the Local Authorities require a rigid gas supply connector, the refrigerator should be located with sufficient space at the back for servicing or, if located against a wall a removable panel of a minimum size of 16" x 20" should be provided in the wall to allow access to the rear of the refrigerator. . If you purchased a CM (CO Monitor model) you must follow instructions in Section 6 - 5.0 onward.

Heat Shield



The heat shield must be installed before operating the appliance. This is a CSA requirement.

Un-wrap the heat shield (located inside the box along with the appliance). Mount heat shield with the screws (supplied) to right side of the fridge.

Heat Shield

Clearances

Minimum clearances to combustible materials are:
Top – 6”
Sides – 2”
Rear – 1”
as shown in Figures. 1, 2 & 3.

Note: DO NOT install the appliance directly on carpeting. Carpeting must be removed or protected by a metal or wood panel beneath the appliance, which extends at least the full width and depth of the appliance.

Fig. #1



Fig. #2



Fig. #3



Fig. #4



Air Flow - to release heat trap

- Fig#1 - This is ideal as both top and sides are open
- Fig#2 – During hot/humid weather this confined area will become very warm. To reduce heat build-up, we recommend providing an area for two air vents to circulate the air. One placed 6” off the floor and the other at or above the appliance top. Cold air return vents with adjustable louvers, works very well. This will allow hot air to evacuate the area and assist in air flow across the fins (similar to air passing across a radiator) – **See Fig #4**
- Fig#3 – If this is your opening you only need to stay the diagrammed distance from the wall and ceiling. There is no need for additional venting.

Gas Connection

Hook-up to the gas supply line: 3/8” SAE (UNF 5/8” - 18) male flare connection. A backup wrench must be used when tightening gas supply fitting. All completed

connections should be checked for leaks with a non-corrosive leak detector and/or soap and water for a bubble check..

WARNING – DO NOT USE FLAME TO CHECK FOR GAS LEAKS

The gas supply system must incorporate a pressure regulator to maintain a supply pressure of not more than 12" water column and no less than 11" water column. (max setting)

Make sure the refrigerator and any other high BTU appliances on your line are turned on when checking the gas pressure. The appliance and its individual shut-off valve must be disconnected from the gas supply piping system during any pressure testing of that system at pressures in excess of ½" psig.

In case detailed instructions on the installation and connection of the gas supply are required, contact your dealer or distributor.

Levelling

Ensure the fridge is level by using a 2ft level. Level the fridge front to back and left to right using the top of the appliance. There are no levelling legs at the back of the appliance just at the front; if the back if your floor is uneven you will have to use shims of some sort to ensure the appliance is level. See importance of level explained on next page.

Chapter

3

General Operating Instructions

Importance of Leveling a Refrigerator

The refrigerator must be adjusted to a vertical position in both directions. In an absorption refrigeration system, ammonia is liquefied in the finned condenser coil at the top rear of the refrigerator. The liquid ammonia then flows into the evaporator (inside the freezer section) and is exposed to circulating flow of hydrogen gas, which causes the ammonia to evaporate, creating a cold condition in the freezer.

When starting this refrigerator for the very first time, the cooling cycle may require up to 4 to 6 hours of running time before the cooling unit is fully operational to begin slowly loading compartment with cold food from your cooler.

The tubing in the evaporator section is specifically sloped to provide a continuous movement of liquid ammonia, flowing downward by gravity through this section. If the refrigerator is operated when not level, liquid ammonia will accumulate in sections of the evaporator tubing. This will slow the circulation of hydrogen and ammonia gas, or in severe cases, completely block it, resulting in a loss of cooling. Warranty will not cover recharge/rebuild if caused by not running the fridge level.

This refrigerator operates on LP Gas (Propane) & 110V (Electricity)

Note: After changing an LP tank, or after a long shut off period, the gas line is likely to be filled with air. You may have to repeat the lighting procedure several times to purge the air out of the gas lines. We suggest first turning off gas at the control panel, then the tank, this will reduce an air trap in the gas line.

Gas Operation – for models with both piezo or electronic ignition

"Start Up" Procedure

Piezo Ignition

1. To start the refrigerator, turn the thermostat knob **E** to maximum setting.

2. Turn button **G** to Gas position, then push **A** button in and hold for the electronic igniter to light the burner, if no electronic ignition exists then repeatedly press **A**, continue to hold the **D** button until you see the needle on the flame sensor **C** has moved from the white into the green area. The burner should now be "on", if not repeat the lighting instructions above. Once in green zone for 15-30 seconds, release **D** button. If there is no click sound while depressing the A button the batteries need changing.

3. Adjust the thermostat knob to desired temperature setting after 4 to 8 hours of operation.

Electronic Ignition (battery)

1. To start the refrigerator, turn the thermostat knob **E** to maximum setting.

2. Turn button **G** to Gas position, then push **A** button in and hold for the electronic igniter to light the burner, continue to hold the **D** button until you see the needle on the flame sensor **C** has moved from the white into the green area. The burner should now be "on", if not repeat the lighting instructions above. Once in green zone for 15-30 seconds, release **D** button. If the is no click sound while depressing the **A** button the batteries need changing**.**

3. Adjust the thermostat knob to desired temperature setting after 4 to 8 hours of operation.

4. To change the batteries in the electronic ignition button to the left to expose the battery, remove AA battery and replace with new one, replace the knob and turn the to the right to close.

Note: If using CO-Monitor, the monitor must be hooked up and be reset with the battery installed for the flame to stay on – Refer to Chapter 6

Shut Down Procedure – Gas Operation

1. Turn selector knob **G** to the **OFF** position
2. Shut the gas off at the LP-gas supply cylinder when the appliance is not in use.
3. If the refrigerator will not be in operation for a period of weeks, it should be emptied, defrosted, cleaned and the doors left open.

110V Operation

1. Ensure the electrical cord is plugged into a grounded outlet

2. Turn the selector switch **G** to AC position, AC power indicator **F** will illuminate

3. To start the refrigerator, turn the thermostat knob **E** to maximum setting.

4. Adjust the thermostat knob to desired temperature setting after 4 to 8 hours of operation.

CONTROLS – See Fig 5. for description of controls

Figure #5



Thermostat

The refrigerator cooling temperature is controlled by a combination thermostat that can be adjusted by turning knob **E** to different settings to maintain the desired refrigerator temperature. It also incorporates a safety device which automatically shuts off the supply of gas if the flame goes out. The piezo electric igniter and/or the electronic ignition discharges sparks onto the burner when the appropriate button is pushed. *See Figure #4*

1. **"MIN" Setting on the Gas Thermostat:** In gas operation, the thermostat closes its main valve and the burner runs continuously at the bypass rate or pilot flame. (counter clockwise turn)

2. **"MAX" Setting of the Thermostat:** In gas operation, the thermostat allows the burner to remain on high flame continuously. (Clockwise turn)

3. The thermostat can be adjusted between "Max" and "Min" (4 or 1) to obtain the desired fridge temperature.

When the thermostat reaches the set temperature, it will cut the burner back to bypass operation.

The setting of the thermostat is critical and recommend it be adjusted to maintain a dry frost on the cooling fins (approx 38° Freinhight or 3° Celsius). Adjust the thermostat knob closer to "Max" (clockwise) when the outside temperature rises.

NOTE: When first turning refrigerator on, move refrigerator controls to maximum, which is the recommended initial setting. After 24 hours, adjust the controls as needed.

How To Use The Refrigerator

FOOD STORAGE COMPARTMENT

The food storage compartment is completely closed and unventilated, which is necessary to maintain the required low temperature for food storage. The coldest areas in the refrigerator are under the cooling fins and at the bottom of the refrigerator. The warmer areas are on the upper door shelves. This should be considered when placing different types of food in the refrigerator.

FROZEN FOOD STORAGE COMPARTMENT

Quick frozen soft fruits and ice cream should be placed in the coldest part of the compartment which is at the bottom. Frozen vegetables, may be stored in any part of the compartment.

This compartment is not designed for deep or quick freezing of food. Meat or fish, whether raw or prepared, can be stored in the frozen food storage compartment provided they are pre-cooled in the refrigerator. To prevent food from drying out, keep it in covered dishes, containers, plastic bags or wrapped in aluminum foil.

Defrosting

Frost will gradually accumulate inside the refrigerator and freezer surfaces. It must not be not allowed to grow too thick as it acts as an insulator and adversely affects the refrigerator performance. Check the formation of frost every couple of weeks and when it exceeds 1/2" thick or more defrost the refrigerator.

Shut off and empty the refrigerator, leaving the fridge and the freezer doors open. Defrosting time can be reduced by filling the ice tray with hot water and placing it in the freezer compartment. You can also open the doors without shutting off the appliance to defrost the fridge; the process will just be a bit slower.

DO NOT USE A HOT AIR BLOWER, PERMANENT DAMAGE COULD RESULT , DO NOT USE A KNIFE, AN ICE PICK, OR ANY OTHER SHARP TOOLS TO REMOVE FROST FROM THE FREEZER COMPARTMENT.

FRIDGE SECTION

Inside the refrigerator compartment, the defrost water runs from a collector channel to a drip tray/cup at the rear of the refrigerator where it normally evaporates. If heavy frost has built up on the cooling fins creating a lot of defrost water, **Beware your water reservoir may overflow, we suggest you inspect reservoir before/after cycle.**

FREEZER SECTION

This area must be wiped down with cloths to remove water after defrosting; there is no drain for this compartment

When all frost is melted in the freezer compartment & interior of the refrigerator it should be wiped up with a clean cloth. Replace all food and set the thermostat to your desired setting.

Cleaning

Cleaning the refrigerator is usually done after it is defrosted or put into storage. To clean the interior liner of the refrigerator, use lukewarm weak soda solution. Use only warm water to clean the finned evaporator, gasket, ice trays and shelves.

Never use strong chemicals or abrasives to clean these parts as the protective surfaces will be damaged. It is important to always keep the refrigerator clean. Dishwasher detergent is recommended

Inside Light

The interior light turns on when the door is open. The light uses four AA batteries located at the back of the appliance.

To change the batteries, use the following procedure:

1. Go to the back of the appliance and remove the cover held in place by 4 Phillips screws

2. Remove and replace the 8 x AA batteries

3. Replace the cover and 4 Phillips screws

4. The light will come on when the fridge door is open, and will shut off when the fridge door is closed by a switch located at the upper right hand side of the inner portion of the fridge. You can check its operation by manually pressing and releasing the switch.

Shut Down Procedure

A. Turn gas valve knob to the "off" position

B. If the refrigerator will not be in operation for a period of weeks, it should be emptied, defrosted, cleaned and the doors left open. The ice tray should also be dried and kept outside the cabinet, also turn off gas at the main supply source.

Chapter

4

Maintenance & Service

The user should be aware of service that must be done on a regular schedule to keep the refrigerator operating properly. Installation must be by a licensed gas fitter in accordance with local codes or in the absence of local national Fuel Gas Code, ANSI Z233.1 and in Canada B149.2 Propane Storage and Handling Code (latest edition).

REFRIGERATOR REMOVAL and PERIODIC MAINTENANCE

Before working on the refrigerator, shut off the gas supply. Disconnect the gas supply line at the rear of the refrigerator. Always use a back up wrench when loosening and tightening this connection. Cap the gas supply line and remove the refrigerator. Replacement is the reverse of removal. Check all connections for gas leaks.

Refer to Chapter 2 - Installation

To keep your refrigerator operating effectively and safely, periodic inspection and cleaning of several components is recommended once or twice a year, sometimes more often depending on environment.

- It's important to keep the area at the back of the refrigerator clean. Clean the coils on the back of the refrigerator. Use a soft bristled brush to dust off the coils.

Note: **The following maintenance is required at least once or twice a year at least.**

- Check all connectors in the complete refrigerator LP gas system for gas leaks. The LP gas supply must be turned on. Apply a non corrosive bubble solution to all LP connections. The appearance of bubbles indicates a leak and should be repaired **immediately** by a qualified serviceman.

WARNING – DO NOT USE FLAME TO CHECK FOR GAS LEAKS

Check burner flame for proper appearance. The flame should be light blue with no yellow at the tip. **See figure #6**





- The LP gas pressure should be checked and the main regulator readjusted if pressure is incorrect. The correct operating pressure is 11" W.C. (water column).
- Inspect the flue baffle, it should be clean and free of soot. Any soot formation indicates improper functioning of the burner. The flue and burner both require cleaning in the following manner:
    - Remove cover from the burner housing.
    - Remove the burner by removing the burner mounting screw
    - Remove the wire and flue baffle from the top of flue tube. Clean the flue from the top using a flue brush and **be sure to cover the burner if remaining intact** to eliminate dirt falling into burner. Blowing compressed air into the flue should clean out soot and scale. Replace the flue baffle.
    - Clean burner tube with compressed air, check for fluff or spider webs.
    - Before removing burner orifice, clean burner area of any soot, scale or dirt. Remove the orifice/burner jet and soak it in alcohol (isopropyl alcohol or thinners) and blow it out with compressed air. Re-install and tighten burner orifice.
    - Replace burner



Warning - DO NOT use a pin or wire when cleaning the burner orifice as damage can occur to the precision opening. This can cause damage to the refrigerator or create a fire hazard. It will also create extremely dangerous levels of carbon monoxide.

- The inlet & outlet gas fittings on the refrigerator need to be checked for leaks. Apply a non corrosive bubble solution to the fittings and observe for leaks. The safety valve will not allow gas pressure to any connections between it and the burner orifice. These fittings must be checked while burner is in operation (gas flow will be present between safety valve and burner head)



WARNING – The gas button **D Fig#5** must be manually depressed to allow gas pressure to flow to the burner orifice. Be sure to apply the leak check solution before depressing the safety shut–off. DO NOT allow any open flame, sparks, smoking, etc. in the area of the test. DO NOT depress safety shut-off for over 30 seconds.



- If leak occurs, then allow ten minutes to dissipate from the burner area. Fix leak then light the burner according to the instructions under GENERAL OPERATING INSTRUCTIONS – GAS OPERATION, CHAPTER 3

Chapter

5

TROUBLESHOOTING INSTRUCTIONS & SUGGESTED SPARE PARTS TO KEEP ON HAND

REFRIGERATOR DOES NOT COOL, CHECK LIKELY CAUSES:

1. Burner orifice clogged. Clean. See section Maintenance & Service, CHAPTER 4,
2. Check to ensure refrigerator is level – (left to right and front to back).
3. Restriction on air flow across cooling unit.
4. Heavy frost build-up on evaporator fins. Defrost.
5. Flue baffle not inserted properly in flue tube.
6. Improperly set thermostat. See paragraph on thermostat. In hot weather or heavy use the setting should be closer to "Max" than usual.
7. Burner dirty. Clean. See Section MAINTENANCE & SERVICE, CHAPTER 4, PERIODIC MAINTENANCE
8. LP gas pressure low at burner. Regulator pressure must not drop below 11 inches W.C (water column). CHAPTER 2, GAS CONNECTION
9. Burner not located properly under the flue tube. Relocate, flame must be directly into flue
10. Burner damaged. Replace.
11. Odours and fumes
    - Dislocated burner
    - Damaged Burner
    - Dirty orifice
    - Dirty flue tube – CHAPTER 4.

Spare Parts

The following is a list of commonly used parts which are available:

- Burner orifice
- Burner
- Electrode with wire
- Thermocouple
- Combination Safety valve & Thermostat
- Baffle

Contact your dealer or an authorized service center for parts and repairs as needed.
Quote Model & Serial # - See CSA rating/serial plate on inside left wall.



Chapter

6

Carbon Monoxide Monitor Instructions for Model - UGP-6C/8C/10C

Unique to Canada only

UNIQUE®

OWNER'S MANUAL
Model 9RV-SSO

Carbon Monoxide Alarm for Appliance Safety Shutoff
ATTENTION: PLEASE READ, FOLLOW AND SAVE!
(See Additional Instruction Sheet for Safety Shutoff Connection)

Dear New COSTAR 9RV-SSO Owner,

Congratulations as you have taken steps to help insure the health and life safety of you and your family. We are proud to offer you our unique, patented CO Sensor technology that detects CO in a manner similar to the human body's response. Please read this owner's manual carefully so you will have a better understanding of the effects of CO poisoning and the COSTAR 9RV-SSO Alarm in conjunction with our UNIQUE propane refrigerator.

To your good health and safety,

Unique Gas Products

⚠ **WARNING***:* Failure to replace this product by the "REPLACE BY DATE" printed on the alarm cover may result in death by Carbon Monoxide poisoning.

Replace by date is six (6) years from date of manufacture.

1.0 WHAT YOU SHOULD KNOW ABOUT CO

Carbon monoxide (CO) is an insidious poison. It is a colorless, odorless and tasteless gas. It is a cumulative poison. The following symptoms are related to CARBON MONOXIDE POISONING and should be discussed with ALL members of the household:

MILD EXPOSURE
Slight headache, nausea, vomiting, fatigue (often described as "flu–like" symptoms)

MEDIUM EXPOSURE
Severe throbbing headache, drowsiness, confusion, fast heart rate

EXTREME EXPOSURE
Unconsciousness, convulsions, cardio respiratory failure, death

Many cases of reported CARBON MONOXIDE POISONING indicate that while victims are aware they are not well, they become so disoriented they are unable to save themselves by either exiting the building or calling for assistance. Also, young children and household pets may be the first affected.

Your CO alarm is designed to detect the toxic CO fumes that result from incomplete combustion, such as those emitted from appliances, furnaces, fireplaces and auto exhaust. A CO Alarm is NOT A SUBSTITUTE for other combustible gas, fire or smoke alarms. This carbon monoxide alarm is designed to detect carbon monoxide gas from ANY source of combustion.

CAUTION: This alarm will only indicate the presence of carbon monoxide gas at the sensor. Carbon monoxide gas may be present in other areas.

CAUTION: This product is intended for use in ordinary indoor locations of family living units. It is not designed to comply with Occupational Safety and Health Administration (OSHA) commercial or industrial standards. Individuals with medical problems may consider using warning devices that provide audible and visual signals for carbon monoxide concentrations under 30 ppm. .

2.0 WHAT YOU SHOULD DO IF THE ALARM SOUNDS

⚠WARNING: Activation of this device indicates the presence of carbon monoxide (CO) which can KILL YOU. If alarm sounds:

For Users in the United States, follow the protocol in steps 1 through 4 below:

1 Operate reset/silence button;
2 Call your emergency services (____ - _____) [fire department or 911];
3 Immediately move to fresh air – outdoors or by an open door/window. Do a head count to check that all persons are accounted for. Do not reenter the premises nor move away from the open door/window until the emergency services responders have arrived, the premises have been aired out, and your alarm remains in its normal condition.
4 After following steps 1-3, if your alarm reactivates within a 24 hour period, repeat steps 1-3 and call a qualified technician (____ - _____) to investigate for sources of CO from fuel burning equipment and appliances, motor vehicles or other sources and inspect for proper operation of this equipment. If problems are identified during this inspection, have the equipment serviced immediately. Note any combustion equipment not inspected by the technician and consult the manufacturers' instructions or contact the manufacturers directly for more information about CO safety and this equipment. Make sure that motor vehicles are not and have not been operating in an attached garage or adjacent to the residence.

For users in Canada, follow the protocol in steps 1 and 2 below:

1. Immediately move to fresh air/outdoors or by an open door or window. Check that all persons are accounted for. Do not re-enter the premises or move away from the open door/window until the emergency services responders have arrived; the premises have been aired out, and your alarm remains in its normal condition;
2. Call your emergency services (___ - _____) [fire department or 911]; If "service" signal sounds (RED LED flashes and horn beeps every 30 seconds); contact your retailer the manufacturer for troubleshooting and/or instructions to return the unit:

2.1 IMPORTANT CONSIDERATIONS:

The **COSTAR** *9RV-SSO* has been designed and is warranted to operate for six years. Never disconnect the battery to silence an alarm. The alarm will automatically sense when the level of CO in the air falls below the danger level. You should stay outside the residence or unconditioned area and remain in fresh air until the alarm is silenced. When the alarm sounds, do not stand too close to the alarm. The sound produced by the alarm is loud because it is designed to awaken a person in an emergency. Prolonged exposure to the alarm at a close distance may be harmful to your hearing.

3.0 DEVELOPING YOUR OWN CO SAFETY PLAN

This CO alarm can quickly alert you to the presence of CO — it cannot prevent toxic CO emissions. Please note that there are hazards against which CO detection may not be effective, such as gas leaks or explosions. The ultimate responsibility for protection against toxic CO fumes rests solely on you. Installing CO detectors is just the first step in protecting your family from toxic CO poisoning. We also suggest that you create an effective, comprehensive safety program as outlined below.

3.1 Install CO detectors properly following the instructions in this manual.

3.2 Develop a family escape plan and practice it with your entire family, especially small children.

- Draw a floor plan of your home and find two ways to exit from each room. There should be one way to get out of each bedroom without opening the door.

- Make sure that all occupants know what the CO alarm signal means and how they must exit the residence by themselves if necessary.

- Decide on a meeting place a safe distance from your house and make sure all occupants understand where they should go and wait if there is a dangerous CO condition.

- Conduct CO safety drills at least every 6 months to make sure that everyone, even small children, know what to do in order to escape safely.

- Know where to go to call the Fire Department or professional assistance from outside your residence.

– Know where to go call the emergency service provider and or a qualified service technician.

4.0 IMPORTANT: WHAT YOUR CO ALARM CAN AND CANNOT DO

4.1 This unit is designed to detect carbon monoxide (CO) and shutoff an appliance for safety only.

4.2 This CO alarm is designed for use within a single residential living unit. It is designed to detect carbon monoxide (CO) entering its sensing chamber. It does not sense combustible gas (such as natural gas, propane or (butane), heat, smoke or flames

4.3 This CO alarm may not provide early warning for occupants if it is placed outside of the house, such as on outside porches.

4.4 When properly located, installed, and maintained, this CO alarm is designed to provide early warning of developing poisonous CO conditions at a reasonable cost. This alarm monitors the air, and when it senses CO, it activates its built-in alarm. It can provide precious time for you and your family to escape from your residence before CO can seriously injure or kill. However, such an early warning is possible only if the alarm is located, installed, and maintained as specified in the Owner's Manual and the Instruction for the Safety Shutoff Connection.

5.0 INSTALLING THE COSTAR *9RV-SSO*

5.1 One of the most important considerations in any CO alarm system is the location of the alarms. Statistics of the National Fire Protection Association (NFPA) show that most of the fatal CO occurrences happen at night while people are sleeping and/or while they are in the garage. Early warning of CO is best achieved by the correct installation of CO alarms.

5.2 This CO alarm may be mounted on the wall.

WALL LOCATION:
Mount the alarm at least 3 feet (usually 5 – 6 feet) from the floor.



Figure 1: *Recommended CO alarm wall*

mounting location is 5 to 6 feet from floor

5.3 **LOCATIONS TO AVOID**: Nuisance alarms are caused by placing units where they will not operate properly. To avoid nuisance alarms, do not place units:

– Within 5 feet (1.5m) of any cooking appliance or furnace.

– Near an open window or door, because the fresh air entering the opening may delay CO from reaching the alarm.

– In damp or very humid areas or next to bathrooms with showers. Install detectors at least 10 feet (3 meters) away from bathrooms.

– In very cold or very hot environments or in unheated buildings or outdoor rooms where the temperature can go below or above the operating range of the alarm. Temperature limits for proper operation are -20° F to 120° F (-29° C to 49° C); Operating Humidity is 10 – 95% RH.

– Good ventilation is recommended when household cleaning supplies or similar contaminants are used.

5.4 **CONDITIONS WHICH CAN RESULT IN TEMPORARY CO SITUATIONS**:

5.4.1 Excessive spillage or reverse venting of fuel burning appliances (woodstoves, etc) caused by outdoor ambient conditions, such as:

1 Wind direction and/or velocity, including high gusts of wind. Heavy air in the vent pipes (cold/humid air with extended periods between cycles).
2 Negative pressure differential resulting from the use of exhaust fans, lack of combustion air entering building or dwelling.
3 Simultaneous operation of several fuel burning appliances competing for limited internal air.
4 Vent pipe connections vibrating loose from clothes dryers, furnaces, refrigerators, or water heaters.
5 Obstructions in or unconventional vent pipe designs which can amplify the above situations.

5.4.2 Extended operation of un-vented fuel burning devices (range, oven, fireplace, etc.)

5.4.3 Temperature inversions which can trap exhaust gasses near the ground.

5.4.4 Car or generator idling in an open or closed area garage, or near a home.

6.0 INSTALLATION INSTRUCTIONS: READ CAREFULLY BEFORE INSTALLING ALARM

CAUTION: THIS UNIT IS SEALED. THE COVER IS NOT REMOVABLE!

6.1 Select proper location (See section 5.0)

6.2 A mounting plate is provided on the back of the alarm. Remove the mounting plate from the back of the alarm by holding the mounting plate and twisting the alarm in the direction indicated by the "OFF" arrow on the alarm cover.



Step A: Wall Alignment





Step B: Alarm Activation **Step C: Removal and Installation**

Figure 2: Installation Instructions

6.3 To insure aesthetic alignment of the alarm with the hallway or wall, the UP ↑ arrow on the mounting plate must be vertical when wall mounting:

(See Step A in Figure 2)

6.4 As described in Figure 2, attach the mounting plate on the wall. Use the screws and anchors provided to secure the mounting plate.

6.5 The battery is INSTALLED REVERSED FOR SHIPPING. Remove and reinstall the battery in the correct orientation as noted on the inside of the battery door. When installing the battery, align the "+" and "-" battery terminals on the correct contacts. The alarm will beep once indicating proper battery installation.

WARNING: Battery is required for operation of appliance, alarm operation and detection of carbon monoxide. If no battery is installed, the appliance will not stay lit. The battery door will not close easily and the unit will not attach to the mounting bracket.

6.6 Twist the alarm in the direction indicated by the "ON" arrow on the alarm cover (see step D) until it locks in place.

6.7 To make your carbon monoxide alarm tamper resistant, a locking pin has been provided in the bag with the screws and anchors. Using this pin will deter children and others from removing the alarm from the mounting plate. To use the pin insert it into the hole in the side of the alarm after the alarm has been installed on the mounting plate (See Figure 3). Note the tamper resist pin will have to be removed in order to change the battery; this can be done easily with a long nose pliers. Using the long nose pliers pull the pin out of the hole, it is now possible to remove the alarm from the mounting plate.



Figure 3: *Tamper Resistant Locking Pin*

6.8 This box contains two self-adhesive labels. You should write the telephone numbers of the emergency service provider and a qualified technician in the space provided on the labels. Place

one label next to the alarm, and the other label near a source of fresh air where you plan to gather after the alarm indicates the presence of carbon monoxide.

7.0 ALARM SIGNALS

7.1. **NORMAL OPERATION**: RED L.E.D. flashes once every 30 seconds, indicating that the alarm is powered

7.2 **ALARM CONDITION**: Repeating signal pattern: RED LED turns "on" for 2 seconds with 4 short beeps and then 5 seconds of silence. Pushing and holding the test/reset button for 3 seconds will silence the alarm for about 4 minutes. After 4 minutes, the alarm will once again sound until the unsafe CO concentration is reduced.

7.3. **TROUBLE/SERVICE CONDITION**: The alarm self-tests every 10 minutes. The alarm will beep and the RED LED flashes once every 30 seconds if a fault is detected. This is an indication of a malfunction and that the detector requires immediate servicing or replaced

7.4. **LOW BATTERY**: RED LED flashes and horn chirp every 30 seconds. Replace battery when this signal occurs

8.0 MAINTENANCE CLEANING YOUR ALARM:

8.1. Keep your CO alarms clean – use a damp (water only) cloth or vacuum.

8.2. To clean your alarm, remove it from the mounting bracket as outlined in Figure 2 Step D: Installation/Removal. IF TAMPER RESISTANT PIN HAS BEEN USED, REFER TO STEP 6.7 UNDER INSTALLATION INSTRUCTIONS FOR REMOVAL INSTRUCTIONS. (See Figure 3)

8.3 You can clean the interior of your alarm by using your vacuum cleaner hose and vacuuming through the openings around the perimeter of the alarm.

8.4 The outside can be wiped with a cloth.

8.5 After cleaning, reinstall your alarm and test your alarm by using the TEST button.

8.6 Test your detectors weekly and repair or replace them when they no longer function. As with any electronic product, alarms have a limited life and alarms that do not work cannot protect you. (See section 10.0)

WARNING: Do not use any household cleaning agents, paints, varnishes

or any other chemical on your **COSTAR** *9RV-SSO* alarm.

9.0 BATTERY REPLACEMENT:

NOTE: IF TAMPER RESISTANT PIN HAS BEEN USED, REFER TO STEP 6.7 UNDER INSTALLATION INSTRUCTIONS FOR REMOVAL INSTRUCTIONS. (See Figure 3)

9.1 To replace the battery remove the alarm from the mounting plate by rotating the alarm in the direction of the "OFF" arrow on the cover (See Figure 2 Step D). Remove and reinstall the battery in the correct orientation as noted on the inside of the battery door. The alarm will beep once indicating proper battery installation. After re-installing the battery, place the alarm on the mounting plate. Twist the alarm in the direction indicated by the "ON" arrow on the alarm cover (see Figure 2 step D) until it locks in place.

9.2 The **COSTAR** *9RV-SSO* CO Alarm uses one (1) 9 volt alkaline battery. A fresh battery should last for one year under normal operating conditions. They can be purchased anywhere batteries are sold, such as your local hardware store.

9.3 USE ONLY THE FOLLOWING 9 VOLT BATTERY FOR CO ALARM REPLACEMENT:

Alkaline type: DURACELL: MN1604

WARNING USE ONLY THE BATTERY SPECIFIED. USE OF DIFFERENT BATTERIES MAY HAVE A DETRIMENTAL EFFECT ON THE CO ALARM. THE CONSTANT EXPOSURES TO HIGH OR LOW TEMPERATURES OR HIGH HUMIDITY MAY REDUCE BATTERY LIFE. CHECK THE BATTERY MANUFACTURERS SPECIFICATIONS FOR PROPER OPERATING CONDITIONS.

Note: Most batteries are not rated below -20°C or above 54°C

10.0 PERIODIC ALARM TESTING:

Test the alarm for proper operation by pushing the test button until a short beep is heard (approximately three seconds). Release the button. The alarm will then test itself for proper operation and the RED L.E.D. light will flash 4 - 6 times. At completion of the self test, the alarm will sound 2 patterns. The alarm then resumes normal operation.

WARNING: THIS TEST PROCEDURE **WILL TURN OFF** THE

APPLIANCE ONCE THE ALARM RESUMES NORMAL OPERATION, RE-LIGHT APPLIANCE FOLLOWING LIGHTING INSTRUCTIONS.

WARNING: RESIDENTIAL USE: TEST ALARM OPERATION AT LEAST ONCE PER WEEK DURING USE OR IF APPLIANCE WAS TURNED OFF FOR A PERIOD OF TIME.

11.0 SERVICE AND WARRANTY

If after reviewing this manual you feel that your CO Alarm is defective in any way, do not tamper with the unit. Call your retailer where you purchased, and they will handle the claim through UNIQUE..

Chapter

7

Door Removal & Reversal Instructions

NOTE: The direction in which your refrigerator doors open (door swing) can be reversed, from left to right or right to left, by moving the door hinges from one side to the other. Reversing the door swing, should be performed, by a qualified person.

1. Remove top hinge cover
2. Remove top hinge with Philips screwdriver and lift freezer door off of center hinge and set door aside.
3. Unscrew center hinge with Phillips screwdriver
4. Lift refrigerator door off of bottom hinge and set aside.
5. Remove bottom hinge with Phillips screwdriver.
6. Now remove all plugs and caps from opposite side and place them in the holes you just remove the screws from.
7. Using a Philips screwdriver fasten the bottom hinge in place using the screws you previously removed.
8. Place fridge door on bottom hinge, then place middle hinge in top hole of fridge door and using the Phillips screwdriver, fasten the middle hinge in place using the screws you previously removed.
9. Now place the freezer door on top of the middle hinge, then place top hinge in top hole of freezer door and using the Phillips screwdriver, fasten the top hinge in place using the screws you previously removed.
10. Tighten all screws while making adjustments where necessary to ensure they are aligned correctly and closing well against the cabinet, this will reduce any excessive frost build up.

Chapter

8

Temperature Controls

NOTE: Due to the nature of a gas operated absorption fridge, temperatures in the fridge compartment will drop to freezing even on the lowest setting when the ambient surrounding the fridge drops to or below 60° F/ 15.0° C overnight and will freeze your food or drink products. An absorption fridge is always cooling when operating, as the ambient drops surrounding the appliance so does the temperate inside the fridge.

COOL DOWN PERIOD

To ensure safe food storage, allow the refrigerator to operate with the doors closed for at least 8 hours before loading it with food.

REFRIGERATOR CONTROL

NOTE: When first setting the controls or when changing a setting, wait 24 hours for the temperature to stabilize before making additional changes.

TEMPERATURE ADJUSTMENT

- **Adjust temperature gradually: move the knob in small increments, allowing the temperature to stabilize.**
- For colder temperatures, turn the knob clockwise.
- For warmer temperatures, turn the knob towards counter clockwise

Turning the refrigerator control will change temperatures in both compartments.

Remember there is no fan to circulate the air in the refrigerator and freezer compartments as in an electric fridge. For good circulation, do not block the cooling fins and try to maintain a temperature of 38° F or 4°C in the fridge

NOTE: When first turning refrigerator on, move refrigerator controls to maximum, which is the recommended initial setting. After 24 hours, adjust the controls as needed.

Looking Inside

SHELF ADJUSTMENT

Refrigerator shelves are easily adjusted to suit individual needs. Before adjusting the shelves, remove all food.

Some shelves are removed by just pulling them toward you and sliding them into a different slot in the fridges cabinet, other shelves are fitted into holes in the sides of the cabinet and require a small clip to be remove from each side of the shelf in order for the shelf to be removed and placed into another accommodating hole.

Crispers & Deli Drawers

The crispers, located under the bottom refrigerator shelf, are designed for storing fruits, vegetables, and other fresh produce. Wash items in clear water and remove excess water before placing them in the crispers. Items with strong odors or high moisture content should be wrapped before storing.

Food Storage Ideas

FRESH FOOD STORAGE

- The fresh food compartment should be kept between 38° F and 40° F (3.3° C and 4.4° C) with an optimum temperature of 38° F (3.3°C).
- Avoid overcrowding the refrigerator shelves. This reduces the circulation of air around the food and results in uneven cooling.

Note: The purchase of a remote thermostat is an ideal way to understand how your appliance functions inside; a sending unit is placed inside your fridge while the temperature display sits on your kitchen counter. You can keep track of the interior temperature of the fridge without opening the fridge door.

FRUITS AND VEGETABLES

- Storage in the crisper drawers traps moisture to help preserve the fruit and vegetable quality for longer time periods.

MEAT

- Raw meat and poultry should be wrapped securely so leakage and contamination of other foods or surfaces does not occur.

FROZEN FOOD STORAGE

- The freezer compartment should be kept at 8.6°F (-13°C) at a 77°F (25°C) room ambient
- A freezer operates most efficiently when it is slowly loaded to 2/3 full.

PACKAGING FOODS FOR FREEZING

- To minimize dehydration and quality deterioration, use aluminum foil, freezer wrap, freezer bags or airtight containers.
- Force as much air out of the packages as possible and seal them tightly. Trapped air can cause food to dry out, change color, and develop an off-flavour (freezer burn).
- Wrap fresh meats and poultry with suitable freezer wrap prior to freezing.
- Do not refreeze meat that has completely thawed.

LOADING THE FREEZER

- Avoid adding too much warm food to the freezer at one time. This overloads the freezer, slows the rate of freezing, and can raise the temperature of frozen foods.
- Leave a space between the packages, so cold air can circulate freely, allowing food to freeze as quickly as possible.
- Avoid storing hard-to-freeze foods such as ice cream and orange juice on the freezer door shelves. These foods are best stored in the freezer interior where the temperature varies less.

Care and Cleaning

Keep your refrigerator and freezer clean to prevent odor build-up. Wipe up any spills immediately and clean both sections at least twice a year. **Never** use metallic scouring pads, brushes, abrasive cleaners or strong alkaline solutions on any surface. **Do not** wash any removable parts in a dishwasher.

- **When moving the refrigerator, pull straight out. You must turn gas off at source or have adequate flex line to move refrigerator. Do not shift the refrigerator from side to side as this may tear or gouge the floor covering and damage the gas supply line.**

- **Damp objects stick to cold metal surfaces. Do not touch refrigerated surfaces with wet or damp hands.**

NOTES:



Do not use razor blades or other sharp instruments, which can scratch the appliance surface when removing adhesive labels. Any glue left from tape or labels can be removed with a mixture of warm water and mild detergent, or, touch the glue residue with the sticky side of tape you have already removed. **Do not remove the certification/serial plate, lighting instructions or CO warning label.**

Chapter

9

Parts Diagram and Lists – UGP 6C/8C/10C



Model UGP 8C



Model UGP 10C



CO-Monitor and Components – all units



UNIQUE - UGP 6C		
Item #	**Part code**	**Part name**
1	N/A	Cabinet
2	DL27501009	Heat sink
3	DL27501005	Drip tray
4	DL00009088	Drainage hose
5	DL10001155	Drip pan
6	DL22001080	Hinge cover
7	DL00003005	Screw
8	DL10001193	Screw cap
9	DL22001079	Top hinge
10	DL22001074	Top hinge cover
11	DLUGP6CFRED	Freezer door
12	DLUGP6CFRID	Fridge door
13	DL10001020	Washer
14	DL00001191	Screw
15	DL18301079	Middle hinge
16	DL08501152	Washer
17	DL22502213	Bottle rack
18	DL22501145	Freezer balcony
19	DL22502240	Fridge balcony
20	DL10001104	Egg tray
21	DL03001003	Ice tray
22	DL18301133	Bottle holder

UNIQUE - UGP 6C		
Item #	**Part code**	**Part name**
23	DL22501047	Crisper
24	DL18301080	Bottom hinge
25	DL08501180	Bottom hinge pin
26	DL00003018	Spring washer
27	DL00003005	Screw
28	DL27501192	Control panel
29	DL27501193	Control label
30	DL00013598	Lamp
31	DL00010053	Foot
32	DL00003068	Screw
33	DL14502072	Castor
34	DL22501163	Top shelf
35	DL22501165	Middle shelf
36	DL22501166	Bottom shelf
37	DL18503055	Cooling unit
38	DL27501060	Heater
39	DL00006007	Glass wool
40	DL18501020	Insulation cover
41	DL27501007	Baffle
42	DL18502082	Baffle holder
43	DL00004003	Screw
44	DL00009306	Washer
44-1	DL10001289	Connector
44-2	DL10001291	Test valve body
44-3	DL18301172	Screw
44-4	DL22501186	Injector
45	DL10001180	Burner assembly
45-1	DL10001177	Burner bracket
45-2	DL10001179	Burner tube support
46	DL10001142	Burner tube
47	DL18301042	Burner cover
48	DL10001186	Cover window
49	DL10001136	Seal ring
50	DL10001113	Nut
51	DL18301122	Pipe
52	DL18301123	Pipe
53	DL10001267	Gas connector
54	DL00003075	Nut
55	DL10001096	Connector bracket
56	DL18301374	Electrode

UNIQUE - UGP 6C		
Item #	**Part code**	**Part name**
57	DL20001077	Piezo ignitor
58	DL18301013	Flame indicator
59	DL18301015	Bracket
60	DL22502241	Balcony spacer
61	DL10001114	Connector
62	DL18301115	Thermostat
63	DL18301029	Nut
64	DL10001115	Connector
65	DL18301005	Safety valve
66	DL22001180	Connector
67	DL10001349	Thermocouple
68	DL18301012	Thermostat bracket
69	DL28801267	Power cord holder
70	DL10001213	Rotary switch
71	DL10001271	Bracket
72	DL18301201	Bracket
73	DL18301033	Knob
74	DL10001327	Connection wire
75	DL10001328	Connection wire
76	DL10001350	Connection wire
77	DL27501137	Front bottom
77-1	DL27501138	Rear bottom
78	DL10001116	Connector
79	DL10001145	Spring
80	DL18301034	Button
81	DL10001252	Power cord
82	DL10001056	Grounding wire
83	DL04001634	Lamp box
84	DL27501160	Lamp board
85	DL04001633	Lamp cover
86	DL04001632	Lamp box bottom
87	DL22001113	Battery
88	DL27501190	Battery holder
89	DL27501191	Battery cover
90	DL00013660	Lamp switch
M1	UGP-9RV-SSO	CO DETECTOR 9RV SSO
M2	QMP-INTERRUPTER BLOCK	INTERRUPTER BLOCK FOR CO-MONITORED FRIDGES
M3	QMP-36”MOSFET	MOSFET ASSY - FOR CO-MONITORED MODELS

ELECTRONIC IGNITION SYSTEM COMPONENTS – NOT SHOWN ON DIAGRAMS		
N/A	DL18301371	Battery Ignitor
N/A	DL22501187	CONNECTION WIRE
N/A	DL18301372	PUSH BUTTON SWITCH
N/A	DL10001418	ELECTRODE
N/A	DL22501138	CONTROL PANEL

UNIQUE - UGP 8C		
Item #	**Part code**	**Part name**
1	N/A	Cabinet
2	DL27501009	Heat sink
3	DL27501005	Drip tray
4	DL00009088	Drainage hose
5	DL10001155	Drip pan
6	Dl22001080	Hinge cover
7	DL00003005	Screw
8	DL10001193	Screw cap
9	DL22001079	Top hinge
10	DL22001074	Top hinge cover
11	DLUGP8CFRED	Freezer door
12	DLUGP8CFRID	Fridge door
13	DL10001020	Washer
14	DL00001191	Screw
15	DL18301079	Middle hinge
16	DL08501152	Washer
17	DL22502213	Bottle rack
18	DL22501145	Freezer balcony
19	DL22502240	Fridge balcony
20	DL10001104	Egg tray
21	DL03001003	Ice tray
22	DL18301133	Bottle holder
23	DL22501047	Crisper
24	DL18301080	Bottom hinge
25	DL08501180	Bottom hinge pin
26	DL00003018	Spring washer
27	DL00003005	Screw
28	DL27501192	Control panel
29	DL27501193	Control label
30	DL00013598	Lamp
31	DL00010053	Foot
32	DL00003068	Screw
33	DL14502072	Castor
34	DL22501163	Top shelf
34-1	DL22501164	Middle shelf
35	DL22501165	Middle shelf
36	DL22501166	Bottom shelf
37	DL22503082	Cooling unit
38	DL27501060	Heater
39	DL00006007	Glass wool

UNIQUE - UGP 8C		
Item #	**Part code**	**Part name**
40	DL22501136	Insulation cover
41	DL27501007	Baffle
42	DL22502227	Baffle holder
43	DL00004003	Screw
44	DL00009306	Washer
44-1	DL22501185	Connector
44-2	DL10001291	Test valve body
44-3	DL18301172	Screw
44-4	DL22501186	Injector
45	DL10001180	Burner assembly
45-1	DL10001177	Burner bracket
45-2	DL10001179	Burner tube support
46	DL10001142	Burner tube
47	DL18301042	Burner cover
48	DL10001186	Cover window
49	DL10001136	Seal ring
50	DL10001113	Nut
51	DL18301122	Pipe
52	DL18301123	Pipe
53	DL10001267	Gas connector
54	DL00003075	Nut
55	DL10001096	Connector bracket
56	DL18301374	Electrode
57	DL20001077	Piezo ignitor
58	DL18301013	Flame indicator
59	DL18301015	Bracket
60	DL22502241	Balcony spacer
61	DL10001114	Connector
62	DL18301115	Thermostat
63	DL18301029	Nut
64	DL10001115	Connector
65	DL18301005	Safety valve
66	DL22001180	Connector
67	DL10001349	Thermocouple
68	DL18301012	Thermostat bracket
69	DL28801267	Power cord holder
70	DL10001213	Rotary switch
71	DL10001271	Bracket
72	DL18301201	Bracket

UNIQUE - UGP 8C		
Item #	**Part code**	**Part name**
73	DL18301033	Knob
74	DL10001327	Connection wire
75	DL10001328	Connection wire
76	DL10001350	Connection wire
77	DL27501137	Front bottom
77-1	DL27501138	Rear bottom
78	DL10001116	Connector
79	DL10001145	Spring
80	DL18301034	Button
81	DL10001252	Power cord
82	DL10001056	Grounding wire
83	DL04001634	Lamp box
84	DL27501160	Lamp board
85	DL04001633	Lamp cover
86	DL04001632	Lamp box bottom
87	DL22001113	Battery
88	DL27501190	Battery holder
89	DL27501191	Battery cover
90	DL00013660	Lamp switch
M1	UGP-9RV-SSO	CO DETECTOR 9RV SSO
M2	QMP-INTERRUPTER BLOCK	INTERRUPTER BLOCK FOR CO-MONITORED FRIDGES
M3	QMP-36"MOSFET	MOSFET ASSY - FOR CO-MONITORED MODELS
ELECTRONIC IGNITION SYSTEM COMPONENTS – NOT SHOWN ON DIAGRAMS		
N/A	DL18301371	Battery Ignitor
N/A	DL22501187	CONNECTION WIRE
N/A	DL18301372	PUSH BUTTON SWITCH
N/A	DL10001418	ELECTRODE
N/A	DL22501138	CONTROL PANEL

UNIQUE - UGP 10C		
Item #	**Part code**	**Part name**
1	N/A	Cabinet
2	DL27501009	Heat sink
3	DL27501005	Drip tray
4	DL00009088	Drainage hose
5	DL10001155	Drip pan
6	Dl22001080	Hinge cover
7	DL00003005	Screw
8	DL10001193	Screw cap
9	DL22001079	Top hinge
10	DL22001074	Top hinge cover
11	DLUGP10CFRED	Freezer door
12	DLUGP10CFRID	Fridge door
13	DL10001020	Washer
14	DL00001191	Screw
15	DL18301079	Middle hinge
16	DL08501152	Washer
17	DL22502213	Bottle rack
18	DL22501145	Freezer balcony
19	DL22502240	Fridge balcony
20	DL10001104	Egg tray
21	DL03001003	Ice tray
22	DL18301133	Bottle holder
23	DL22501047	Crisper
24	DL18301080	Bottom hinge
25	DL08501180	Bottom hinge pin
26	DL00003018	Spring washer
27	DL00003005	Screw
28	DL27501192	Control panel
29	DL27501193	Control label
30	DL00013598	Lamp
31	DL00010053	Foot
32	DL00003068	Screw
33	DL14502072	Castor
34	DL27501061	Top shelf
34-1	DL27501062	Middle shelf
35	DL27501063	Middle shelf
36	DL27501064	Bottom shelf
37	DL22503082	Cooling unit
38	DL27501060	Heater
39	DL00006007	Glass wool

UNIQUE - UGP 10C		
Item #	**Part code**	**Part name**
40	DL22501136	Insulation cover
41	DL27501007	Baffle
42	DL22502227	Baffle holder
43	DL00004003	Screw
44	DL00009306	Washer
44-1	DL22501185	Connector
44-2	DL10001291	Test valve body
44-3	DL18301172	Screw
44-4	DL18301171	Injector
45	DL10001180	Burner assembly
45-1	DL10001177	Burner bracket
45-2	DL10001179	Burner tube support
46	DL10001142	Burner tube
47	DL18301042	Burner cover
48	DL10001186	Cover window
49	DL10001136	Seal ring
50	DL10001113	Nut
51	DL18301122	Pipe
52	DL18301123	Pipe
53	DL10001267	Gas connector
54	DL00003075	Nut
55	DL10001096	Connector bracket
56	DL18301374	Electrode
57	DL20001077	Piezo ignitor
58	DL18301013	Flame indicator
59	DL18301015	Bracket
60	DL22502241	Balcony spacer
61	DL10001114	Connector
62	DL18301115	Thermostat
63	DL18301029	Nut
64	DL10001115	Connector
65	DL18301005	Safety valve
66	DL22001180	Connector
67	DL10001349	Thermocouple
68	DL18301012	Thermostat bracket
69	DL28801267	Power cord holder
70	DL10001213	Rotary switch
71	DL10001271	Bracket
72	DL18301201	Bracket

UNIQUE - UGP 10C		
Item #	**Part code**	**Part name**
73	DL18301033	Knob
74	DL10001327	Connection wire
75	DL10001328	Connection wire
76	DL10001350	Connection wire
77	DL27501137	Front bottom
77-1	DL27501138	Rear bottom
78	DL10001116	Connector
79	DL10001145	Spring
80	DL18301034	Button
81	DL10001252	Power cord
82	DL10001056	Grounding wire
83	DL04001634	Lamp box
84	DL27501160	Lamp board
85	DL04001633	Lamp cover
86	DL04001632	Lamp box bottom
87	DL22001113	Battery
88	DL27501190	Battery holder
89	DL27501191	Battery cover
90	DL00013660	Lamp switch
M1	UGP-9RV-SSO	CO Detector 9RV SSO
M2	QMP-Interrupter Block	Interrupter Block for CO-Monitored fridges
M3	QMP-36”Mosfet	Mosfet Assy - For CO-Monitored Models
Electronic Ignition System Components – not shown on diagrams		
N/A	DL18301371	Battery Ignitor
N/A	DL22501187	Connection Wire
N/A	DL18301372	Push Button Switch
N/A	DL10001418	Electrode
N/A	DL22501138	Control Panel

Warranty

UNIQUE UGP–6C/8C/10C
PROPANE REFRIGERATOR - 3 YEAR LIMITED WARRANTY
(1 year parts – 3 year cooling system)

Unique Gas Products Ltd. *warrants that this* **UNIQUE–6C/8C/10C** *refrigerator is free from defects in material and workmanship under normal usage and service under the following terms:*

1. *This Warranty is made only to the first purchaser ("original purchaser") who acquires this refrigerator for his/her own use and will be honored by* ***Unique Gas Products Ltd.*** *and by the Seller.*

2. *Any part of this refrigerator returned to the Seller or* ***Unique Gas Products Ltd****, which upon examination is determined by them to have been defective in material or workmanship, will at their option be either repaired or replaced under this warranty, without charge for materials/parts. (Customer is responsible for labour)*

3. *The obligation to repair or replace defective parts will apply only to parts returned within one year of the date of purchase and will constitute the Sellers sole obligation under this Warranty.*

The Seller will have no obligation under this warranty with respect to conditions unrelated to the material or workmanship of this refrigerator. Such unrelated conditions include without limitation:

a) *faulty installation (or venting) and damage resulting therefrom; not installed by Seller*
b) *the need for normal maintenance of this refrigerator (including the cleaning of the Burner, Venturi, Orifice, Flue tubes and assurance of proper propane gas pressure);*
c) *any accidents to or misuse of any part of this refrigerator and any alteration thereof by anyone other than the Seller or its authorized representative.*

This **UNIQUE 6C/8C/10C** *refrigerator* ***must*** *be serviced regularly as outlined in the Owner's Manual.* ***Unique Gas Products Ltd.*** *and the seller will not be liable for direct or indirect loss of foods caused by failure in operation. In case of failure, the owner must provide proof of purchase, Model, and Serial Number to the Seller or* ***Unique Gas Products Ltd.***

"CARRY IN" Warranty due to remote locations, it is the customer's responsibility to bring items to dealer for review.

Please fill out warranty card within 30 days and mail back for warranty coverage

2245 Wyecroft Road #5
Oakville, ON, Canada, L6L 5L7
Toll Free: 1-877-427-2266
Ph: 905-827-6154 www.UniqueOffGrid.com Fax: 905-827-2027

LIMITED WARRANTY

COSTAR Model 9RV-SSO

UNIQUE GAS PRODUCTS LTD offers you this limited warranty on your new carbon monoxide alarm, including all of its component parts except the battery. This limited warranty extends solely to the original end-user purchaser of this product, provided your purchase was made from an authorized vendor. Transfer or resale of this product will automatically terminate warranty coverage.

UNIQUE GAS PRODUCTS LTD. warrants the enclosed carbon monoxide alarm to be free from defects in materials and workmanship under authorized use and service, as specified in the owner's manual, for a period of six (5) years from the date of manufacture. All replaced items become the property of UNIQUE GAS PRODUCTS LTD.

UNIQUE GAS PRODUCTS LTD.MAKES NO OTHER WARRANTIES, EXPRESS OR IMPLIED, EXCEPT AS REQUIRED BY LAW, AND IN NO CASE FOR A DURATION LONGER THAN THAT OF THIS WRITTEN WARRANTY, EXCEPT AS REQUIRED BY LAW, INCLUDING, BUT NOT LIMITED TO, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR AGAINST INFRINGEMENT, OR ANY EXPRESS OR IMPLIED WARRANTY ARISING OUT OF TRADE USAGE OR OUT OF A COURSE OF DEALING OR COURSE OF PERFORMANCE. UNIQUE GAS PRODUCTS LTD.has not authorized any other party to extend any other warranties in connection with the sale of the product, and will not accept responsibility for any statements, representations, or warranties made by any other person.

This limited warranty does not cover: (1) 9 volt alkaline battery; (2) products which have been improperly installed, repaired, maintained, modified, or which have been subjected to misuse, abuse, accident, neglect, exposure to fire, water, or excessive changes in climate or temperature, or combined with non-UNIQUE GAS PRODUCTS LTD.. - approved accessories; (3) physical damage caused from use other than normal and proper operation or handling, as specified in the owner's manual; (4) cosmetic damage; (5) products on which warranty stickers or product serial numbers have been removed, altered, or rendered illegible; (6) the cost of installation, removal or reinstallation.

UNIQUE GAS PRODUCTS LTD.SPECIFICALLY DISCLAIMS LIABILITY FOR ANY AND ALL DIRECT, INDIRECT, SPECIAL, GENERAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, INCLUDING, BUT NOT LIMITED TO, LOSS OF PROFITS OR ANTICIPATED PROFITS ARISING OUT OF USE OF OR INABILITY TO USE THE PRODUCT.